

Register Address	Contents	Read/Write	Datablocks	HEX response		Remarks
0000	Voltage	Read	1	HEX response	convert to decimal	divide by 10 to read V (91F = 2335 = 233.5V)
0001	Current	Read	1	HEX response	convert to decimal	divide by 10 to read A
0003	Active power	Read	1	HEX response	convert to decimal	Result is W - divide by 1000 to get kW
0004	Reactive power	Read	1	HEX response	convert to decimal	Result is W - divide by 1000 to get kW
0005	Apparent power	Read	1	HEX response	convert to decimal	Result is W - divide by 1000 to get kW
0007	Active energy	Read/write	2	HEX response	convert to decimal	Result divide by 100 to get kW, 5 blocks of 4 bits; Total; T1; T2; T3; T4
0011	Reactive energy	Read/write	1	HEX response	convert to decimal	Result divide by 100 to get kW, 5 blocks of 4 bits; Total; T1; T2; T3; T4
002a	Baud rate	Read/write	1	signed	no need to convert	01=1200; 02=2400; 03=4800; 04=9600
002b	Meter ID	Read/write	1	HEX response	convert to decimal	000b - broadcast; meter ID between 1-247
002c	Password	Write	2	HEX response	default 00000000	Reset password and write within 10 seconds the command for change meter ID or reset active energy or change the baud rate

Remarks	Active/Reactive energy	read	sent to meter received from meter	00 03 00 07 00 0A [CRC16] 01 03 14 00 00 04 D2 00 00 00 00 00 00 00 00 00 00 23 D8
				01 = meter address 03 = read command 14 = 5 data blocks of 4 00 00 04 D2 = 1234 (= 12,34kWh) for total active energy 00 00 04 D2 = 1234 (= 12,34kWh) for active energy T1 00 00 00 00 = 0000 (= 0,00kWh) for active energy T2 00 00 00 00 = 0000 (= 0,00kWh) for active energy T3 00 00 00 00 = 0000 (= 0,00kWh) for active energy T4
	Active/Reactive energy	reset	reset password received from meter enter this energy reset line within 10 seconds after password reset	00 28 FE 01 00 02 04 00 00 00 [CRC16] 01 28 FE 01 00 01 C9 24 00 10 00 07 00 0A 14 00 00 00 00 00 00 00 00 00 00 00 00 00 [CRC16]
			sent to meter received from meter	00 10 00 07 00 0A F1 CF 01 10 00 07 00 0A F1 CF
	Meter ID		reset password received from meter enter this energy reset line within 10 seconds after password reset sent to meter received from meter	00 28 FE 01 00 02 04 00 00 00 [CRC16] 01 28 FE 01 00 01 C9 24 01 10 00 2B 00 01 02 00 64 [CRC16] 64 10 00 2B 00 01 7B 34

Modbus command line - read data				
Meter ID	Read	Register address	Register length	CRC code
00	03	0000	0001	CRC16 Modbus RTU
00	03	0001	0001	CRC16 Modbus RTU
00	03	0003	0001	CRC16 Modbus RTU
00	03	0004	0001	CRC16 Modbus RTU
00	03	0005	0001	CRC16 Modbus RTU
00	03	0007	000a	CRC16 Modbus RTU
00	03	0011	000a	CRC16 Modbus RTU
00	03	002a	0001	CRC16 Modbus RTU
00	03	002b	0001	CRC16 Modbus RTU

Modbus command line - write data							
Meter ID	Read	Register address	Register length		Data length	New value	CRC code
00	10	0007	0a 14 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00				CRC16 Modbus RTU
00	10	0011	0a 14 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00				CRC16 Modbus RTU
00	10	002a	0001	02	0001		CRC16 Modbus RTU
00	10	002b	0001	02	0001		CRC16 Modbus RTU
00	28	002c	fe 01 00 02 04 00 00 00 00				CRC16 Modbus RTU

0001 = 1200 0002 = 2400 0003 = 4800 0004 = 9600
meter number 1-247 convert to HEX code